

Starfood quick technical guide

TECHNICIAN

- Failure reset

Press top switch inside coin compartment door to reset health timer or failures.

Machine will stop vending if temperature not below 7 degrees in 45 minutes.

- Changing disk segments

Open main door, left hand lock.

Press black button on right, corresponding to disk to be changed

Locate half way point as disk rotates then stops when switch released

Using the 5mm spanner (supplied), unlock the two halves of the disk to allow removal following rotation to bring half to front

Remove the dividers by pressing the catch at the front, top, with the end of the spanner

All divisions must be of equal spacing

Replace door stop into correct opening position

Continue with other disks as necessary

When complete, power down and up, the machine, using the internal main switch, illuminated

The machine will automatically re-configure itself

- Programming

Press lower switch behind coin mech door

Press third selection button (Enter)

Use top selection button to scroll to information required

Press third selection button (Enter) to view data

Press top selection button to scroll

When finished press fourth selection button (Escape)

Close coinage compartment door